

Installation Instructions for 18" 270° Corner Dome 26" 270° Corner Dome

1. Mark wall measuring from corner of wall in
 - A. 18" Dome 4-15/16"
 - B. 26" Dome 6-7/8"and from ceiling desired mounting level.
2. Insert desired fastener (not included) for your style of mounting surface leaving a gap between the head of the screw and wall for Loops. (#10 Panhead screw recommended).
3. Insert loops over screw head

